

# MIXING BARIUM

To mix barium for upper GI studies:

1200 density

32 ounces of EZpaque

32 ounces of water

1400 density

48 ounces of EZpaque

8 ounces of water

Prefilled enema bags

750 cc of water

Do not mix until the preliminary film has been approved by the radiologist.

Make sure to mix well, the barium will fall to the bottom of the container.