

To enable the Browser mode on your SpeechMike proceed as follows:

1. Press EOL and INS/OVR simultaneously for 3 seconds.
2. All corresponding LEDs will start flashing. You can now change the SpeechMike button mode for 10 seconds.
3. **FOR SIRONA** - Click on F3 to switch your SpeechMike to **Browser mode**. The F3-LED will light up to confirm the new button mode setting.
4. **FOR MERITUS** - Click on F1 to switch your SpeechMike to **Event mode**. The F1-LED will light up to confirm the new button mode setting.
- 5.

